

VWS PRODUCT INSTALLATION

1. Magnetizers -

There are two sets of magnetizers that attach with the included zip ties.

The first set attaches to the main water line coming into the house. Proper placement is on the waterline prior to water flowing into the Whole House Filtration System.

The second set attaches to the hot water line coming out of the water heater or tankless system.

2. VWS Whole House Filtration System (WHFS) -

There are 3 filters inside the casing. Be sure to remove the plastic from the new filters prior to use. The included wrench is used to loosen the

filter housing. Do not use it to tighten the filter housing. They should be tightened by hand.

The WHFS needs to be installed right after the first magnetizer on the main water line into the house. Places where they have been installed, the front of the house, side of the house, in the garage, or if it gets cold in the winter in the basement. The plumber or handyman will know this already depending on where you live and will advise you accordingly.

3. Alkaline Ionized Water System-

Installation instructions are included in the box.

The unit goes on top of the counter or can go underneath the sink. For under the sink installation, an Under the Counter (UTC) kit will be required. Install location is customer preference.